ledgebit®

Smart Door/Window Sensor

User Manual

Please read this manual carefully before use and keep it for future reference.

Specifications

Input voltage: DC3V LR03

Quiescent Current: ≤10uA

Alarm Current: ≤160mA

Low power undervoltage: ≤2.7V

WiFi: 802.11 b/g/n

Magnetic control distance: ≥15mm

Working temperature: −10°C to 50°C

Working humidity: max 95%RH

How to use

Push the mounting bracket upward and remove the bracket, then insert the battery.


Insert the battery into the battery compartment according to the polarity markings. After two batteries are installed, the indicator light will turn on and then off.


Download & Install the APP

1. Go to your App Store & search the "Smart Life" & install the app.

2. Input account name and password to login. If you don't have an account, please register an account first. System will identify your country automatically. You can use your mobile phone number as your account name.

3. Tap on "Next" to get a verification code via SMS on your mobile phone. Enter a desired password.

4. Tap on "Confirm" to finish your registration.

Register with email, click "My Home" interface "+" or click "Add Devices" in the middle blank. Select "Sensor" and then press "Contact Sensor Wi-Fi".

Enter the WiFi password according to the prompt and click to confirm.

Press the button on the door sensor. The LED indicator will flash rapidly, then the device will enter automatic network connection mode.

After the network connection is successful, select the door sensor icon in the app. The app will notify "Open" or "Closed" when the magnetic door sensor detects the door opening or closing.